



ABN 12 922 680 167

Phone: 1300 724 008

Mobile: 0414 761 179

Fax: 02 9871 0756

Email: [info@sealchange.com.au](mailto:info@sealchange.com.au)

Web: [www.sealchange.com.au](http://www.sealchange.com.au)

9 Kerribee Pl, Carlingford NSW 2118

## Instructions for Seal Installation (Bead Type)

Thank you for purchasing a door seal from Seal Change.

When you receive the door seal/s, lay them out flat for a day or overnight. This will remove any kinks. Check that the seal/s is the correct size by sizing it up against the door/s.

Loosen the screws located behind your old door seal. You may need a hexi, or Phillips head screw driver. Do not remove the screws completely.

If once you have fitted the new seal you are experiencing problems with the seal 'sticking' on the hinge side, you can either rub some vaseline, silicone spray or baby/talc powder onto the seal and frame to correct this.

Whilst the screws are loose on your door the alignment of the door may twist. The best way to overcome this is to twist the door back into place with just the corner screws tightened.

If the doors have 'dropped' then adjustment of the hinges may be necessary. Again do not completely remove screws or door.

If you have water leaking inside your fridge this may not be fixed by simply replacing the door seals. You may need to clear the drain inside your fridge as the continuing leaking water will damage your new seals also.

If there are any gaps after fitting the seal, you can heat the door seal with a hair dryer. This will soften the door seal and make it more pliable. Ensure the magnet fits tightly against the frame on all sides. Once you are satisfied that the seal is fitted correctly leave the door/s shut for around 2 hours to allow the seal to "take shape".