



ABN 12 922 680 167

Phone: 1300 724 008

Mobile: 0414 761 179

Fax: 02 9871 0756

Email: info@sealchange.com.au

Web: www.sealchange.com.au

9 Kerribee Pl, Carlingford NSW 2118

Instructions for Seal Installation (Flap Type)

Thank you for purchasing a door seal from Seal Change.

When you receive the door seal/s, lay them out flat for a day or overnight. This will remove any kinks. Check that the seal/s is the correct size by sizing it up against the door/s.

Completely remove the screws from the upper top half of the liner and replace old seal with new one.

Put screws back by pushing screws through flap of seal. Lightly tighten up.

Continue to do the same on the left and then right side except that the screws have to be inserted from bottom up while pushing the bottom corners up the lengths. Then do the rest of the seal the same way.

Smear some lubricants like Vaseline onto the hinge side of the seal, especially at the corners and shut the door. If the door closes smoothly but leaves gaps on the top or bottom corners of handle side, then hold the top and bottom corners with your hands and try to twist either in clockwise or anti-clockwise direction until gaps are reduced or disappeared.

If there are still gaps, you can heat the door seal with a hair dryer. This will soften the door seal and make it more pliable. Ensure the magnet fits tightly against the frame on all sides. Once you are satisfied that the seal is fitted correctly leave the door/s shut for around 2 hours to allow the seal to "take shape".

If you have water leaking inside your fridge this may not be fixed by simply replacing the door seals. You may need to clear the drain inside your fridge as the continuing leaking water will damage your new seals also.